

Installation

1. Remove the DCAP AND the Power Supply, set aside. Keep track of the the existing Ethernet cable as it will be reused.
2. Take the new Power Supply and plug into the wall outlet. Place the new DCAP on the wall where the old one was, then plug in the power connector and the Ethernet cable into the DCAP.
3. You should immediately see a green Status LED on the front of the DCAP. In a moment the Status LED will turn orange/red, and then turn green after a minute or two.
4. If the Status LED does not turn green, please check the Ethernet cable; is it connected at both ends, and are there green/amber LEDs at the connector on the DCAP? If the cable seems fine, try replacing the Ethernet cable with the one that came with the new DCAP. If this fails, call your installation team or RBC company, or Tehama Wireless at 415.495.7344, Option 2 for support.
5. If you received a return label with the new DCAP, please place that over the existing shipping label, and put the old DCAP and power supply back in the box. Then drop off at any UPS Store or give to your UPS driver.

